

solar clock

Your clock is supplied with 2 sets of hands

The long hands work best when wall mounting your clock and the short hands are ideal when free standing.


How to change the hands

To remove the hands, pull firmly on the centre.
then press the new ones on!

Do not pull on the arms, this will damage them!



www.suck.uk.com



Setting your clock to work any way up

Turn the clock upright or on its side. Move the hands to exactly 12:00 - the hour hand and the minute hand both pointing directly up. Now set the correct time using the adjustment wheel on the back of the clock.